




UTTERMOST

# ASSEMBLY INSTRUCTIONS

STYLE# 28122-1

*Careful unpack all lamp parts from the carton.*

1. Place the Base in an upright position on the floor.
2. Position the **Part B** onto the **Base**, use **Wrench** to tighten from bottom of base.
3. Assembly the **Part A** onto **Part B** as shown.
4. Install correct Bulbs referring to fixture markings and /or labels for maximum wattage. (Not Included)



28122-1

## IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug ( one blade is wider than the other ) as a safety feature to reduce the risk of electric shock.

This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151  
[www.uttermost.com](http://www.uttermost.com)