




UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE#: 28195-1

Carefully unpack all lamp parts from the carton.

1. Place the **Lamp Base** in an upright position on the floor, be sure the power to the installation point is power off
2. Thread **Part C** into **Lamp base**, turn clockwise to tighten until snug.
3. Thread **Part B** into **Part C**, turn clockwise to tighten until snug.
4. Thread **Part A** into **Part B**, turn clockwise to tighten until snug.
5. Locate the **Harp** into the **Saddle**, and place the **Shade** over the top of the **Harp**, secure by thread the **Finial** onto the **Harp**. Hand tighten until snug.
6. Install correct **Bulb** (Not Included) onto the Socket referring to label for maximum wattage before connecting the plug to the electricity outlet Box.



IMPORTANT SAFETY INSTRUCTIONS

This floor lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock.

This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician.

Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

