




ASSEMBLY INSTRUCTIONS

STYLE#: 28201-1

Careful unpack all lamp parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Thread **Part A** into the **Base** by turning Part A clockwise to tighten until snug.
3. Thread **Part B** into **Part A** by turning Part B clockwise to tighten until snug.
4. Thread **Part C** into **Part B** by turning Part C clockwise to tighten until snug.
5. Thread **Stem** into Nipple by turning Stem clockwise to tighten until snug.
6. Place the **Shade** over the top end of the **Stem**. Secure by thread the **Finial** onto the **Stem**. Hand tighten until snug.
7. Install correct Bulbs referring to fixture markings and /or labels for maximum wattage. (Not Included)



IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151

www.uttermost.com