





UTTERMOST

# Assembly Instruction




## STYLE NO.: 28340-1

1. Take the parts carefully out of carton, and place them on a flat surface, make sure that the parts will not be damaged.

2. Attach the shade onto the socket as drawing and Fasten socket ring onto socket.

CAUTION; IN ACCORDANCE WITH THE UL REGULATION, THE SHADE SHOULD BE OPEN TOP&OPEN BOTTOM AND "CD" IS BIGGER THAN OR EQUALS TO 4, "R" IS NOT SMALLER THAN 3-1/2" OR MAY CAUSE FIRE "H" IS 3-1/4"



To clean, wipe with soft dry cloth.

**NOTE: THE DRAWING OF THE LAMP BODY IS FOR REFERENCE ONLY.**