

UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE#: 28415

Carefully unpack all Assembly parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Thread **Rod** into the **Base** by turning **Rod** clockwise to tighten until snug.
3. Locate the **Harp** by pressing the ends of the **Harp** into the **Saddle** on the top of **Base**.
4. Place the **Shade** over the top end of the **Harp**. Secure by thread the **Finial** onto the **Harp**. Hand tighten until snug.
5. Install correct **Bulbs** referring to fixture markings and /or labels for maximum wattage. (Not Included)

