MANUFACTURERS OF WALL DECOR, LIGHTING,

DECORATIVE ACCESSORIES AND ACCENT FURNITURE

UTTERMOST

ASSEMBLY INSTRUCTIONS

ITEM#28970

Thank you for purchasing this table lamp. Please follow the instructions listed below.

1.Unpack all parts from the carton carefully and lay all of them on a soft surface. Do not plug in until the assembly is completed. 2.First pull the cord from the bottom of the lamp, and then screw the Lamp holder with Neck (A) into the top of the lamp

base Part (B) until secure. (Image A).

3. Then pull the cord lightly and let the Threaded Tube (C) go throw the the Lamp base bottom (D), and then screw it into the bottom of the Lamp base Part (B). **P.S: Do not screw it fully, just screw it in about 4 circles, so that the Threaded Tube (C) will be long enough at the bottom of the base. (Image A).**

- 4.And then insert the bottom of Part (B) into the top of the base (D), make sure they align with each other. And then place the Wash, Spring Wash into the Threaded Tube (C) and use the Nut to secure the base with the Lamp Part (B). If the Threaded Tube (C) not long enough to hold the wash, spring washer and the Nut, pleas go back to Step 3 and unscrew the Threaded Tube a little bit. Wrench included. (Image A)
- 5.Now put the lamp to place where you want it to be. And then screw a 150W Max. bulb into the socket (bulb not included). And then squeeze the bottom of the harp (E) and insert it into the saddle. (Image B).
- 6.Unscrew the Finial(G) and place the shade (F) onto the top of the Harp (E) and then screw the finial (G) to secure it. And now the lamp is assembled. For clean, please use soft cloth. (Image B).





Image B



PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151 www.uttermost.com