


UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE# 29493-1

Careful unpack all lamp parts from the carton.

1. Place the base in an upright position on the floor
2. Put the **Diffuser** onto the top of **Metal Shade** and tightened with **Mounting Ball**.
3. Use ON-OFF 100W bulb (not included).



29493-1

IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock.

This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.