




UTTERMOST

ASSEMBLY INSTRUCTIONS

STYLE# 29589-1

Careful unpack all lamp parts from the carton.

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Install the **Glass** in the **Fixture Body** by inserting **Glass** into channel, then secure in place by bending the tabe from the **Fixture Body** over the edge of the **Glass**.
3. Install correct **Bulbs** referring to fixture markings and /or labels for maximum wattage. (Included)



IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug (one blade is wider than the other) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.