

# UTTERMOST


## ASSEMBLY INSTRUCTIONS

THANK YOU FOR PURCHASING  
THE FLOOR LAMP .  
PLEASE FOLLOW THE INSTRUCTIONS  
LISTED BELOW:

### ASSEMBLY INSTRUCTIONS:

MODEL NUMBER:29990-1

1. UNPACK ALL PARTS FROM CARTON CAREFULLY;
2. THREAD THE TUBE("B") CLOCKWISE TO THE BASE ("A")
- 3.THREAD THE TUBE("C") CLOCKWISE TO THE TOP OF TUBE ("B").
- 4.THREAD THE ASSEMBLY PART ("D") CLOCKWISE TO THE TOP OF TUBE ("C").
5. ATTACHED THE HARP("F") INTO THE SADDLE("E")
- 6.PLACE THE SHADE("G") ONTO THE TOP OF HARP("F"), AND SCREW THE DISC ("H") AND FINIAL ("I") CLOCKWISE TO FIX THE SHADE



### IMPORTANT SAFETY INSTRUCTION:

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER). AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.