


# UTTERMOST

## ASSEMBLY INSTRUCTIONS



### Assembly Instruction

STYLE NO.: 30134

1. Take the parts carefully out of the carton, and place them on a flat surface, make sure that the parts will not be damaged.

2. Screw the pipe closewise to the top of lamp body.

3. Place the finial disc and the shade on the pipe, then tighten the finial clockwise until secure.

CAUTION: IN ACCORDANCE WITH THE UL REGULATION, THE SHADE SHOULD BE OPEN TOP & OPEN BOTTOM AND "CD" IS BIGGER THAN OR EQUALS TO  $3\frac{1}{2}$ ", "R" IS NOT SMALLER THAN  $2\frac{1}{2}$ " OR MAY CAUSE FIRE. "H" IS  $3\frac{1}{4}$ ".

To clean, wipe with soft dry cloth.

NOTE: THE DRAWING OF THE LAMP BODY IS FOR REFERENCE ONLY.