

UTTERMOST


ASSEMBLY INSTRUCTIONS

STYLE NO: 30613-1

Thank you for purchasing this Uttermost Table Lamp.

Please follow the instructions listed below to assemble.

1. Take all parts carefully out of the carton and place on a flat surface to be sure no parts are damaged.
2. Place the Shade (B) onto the top of Socket (A), and Screw the Ring (C) clockwise to secure the Shade.
3. Lamp and Shade Assembly is complete.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other), as a safety feature to reduce the risk of electric shock.

This plug will fit in a polarized outlet only one way.

If it does not fit fully in the outlet, reverse the plug.

If it still does not fit, contact a qualified electrician.

Never use with an extension cord unless plug can be fully inserted.

Do not alter this plug.

Care and Maintenance

To clean, wipe with a soft dry cloth.