
UTTERMOST
ASSEMBLY INSTRUCTIONS

ASSEMBLY INSTRUCTIONS
MODEL NUMBER 30735-1
THANK YOU FOR PURCHASING THIS RECHARGEABLE LED TABLE LAMP
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:



1. Take the parts carefully out of the carton and place them on a flat surface to prevent any damage.


2. Plug the charging cord (not included) into the charging port for to fully charge the lamp before the first use.

3. To adjust the brightness of the lamp, touch and hold the Touch Dimmer Switch at the top of the lamp.

The light can change from dim to bright or from bright to dim depending on the current light level.

Care and Maintenance
To clean, wipe with a soft dry cloth.

ASSEMBLY INSTRUCTIONS
MODEL NUMBER 30735-1
THANK YOU FOR PURCHASING THIS RECHARGEABLE LED TABLE LAMP
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:



1. Take the parts carefully out of the carton and place them on a flat surface to prevent any damage.

2. Plug the charging cord (not included) into the charging port for to fully charge the lamp before the first use.

3. To adjust the brightness of the lamp, touch and hold the Touch Dimmer Switch at the top of the lamp.

The light can change from dark to bright or from bright to dark depending on the current light level.

Care and Maintenance
To clean, wipe with a soft dry cloth.