
UTTERMOST
ASSEMBLY INSTRUCTIONS

STYLE NO: 30911-1

Thank you for purchasing this Uttermost Table Lamp.

Please follow the instructions listed below to assemble:



1. Take all parts carefully out of the carton and place them on a flat surface to prevent any damaged or missing parts.
2. Thread Tube (F) clockwise onto Base (G).
3. Thread Saddle (E) clockwise onto the top of Tube (F).
4. Attach Harp (D) into the Saddle (E).
5. Place Shade (C) onto the top of Harp (D) and screw the Finial Disc (B) and Finial (A) clockwise to secure the Shade.
6. Lamp and Shade Assembly is Complete.

IMPORTANT SAFETY INSTRUCTION:

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER). AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK.THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.