

UTTERMOST

ASSEMBLY INSTRUCTION FOR ITEM # 50194



① Top – 1 pc



② Leg – 2 pcs



A Bolt – 12 pcs



B Spring Washer – 12 pcs




C Washer – 12 pcs




D Allen Key – 1 pc

1




NOTE : : Connect the Top (No.1) and Leg (No.2). With the Allen Key (D), install the Bolts (A), Spring Washer (B), and Washer (C) then tight them.

2



3



Assembly is completed

P.O. Box 558 | 3325 Grassy Hill Road | Rocky Mount, VA | 24151
www.uttermost.com