
UTTERMOST
ASSEMBLY INSTRUCTIONS

Assembly Instructions

STYLE NO: 51252



1. Take all parts carefully out of the carton and place them on a soft, level surface to prevent any damaged or missing parts.

2. Insert the Rechargeable LED Lightsource (B) into the Body (C) using the magnetic plate provided with the Lightsource.

3. Place the Table Top (A) into the top of Body (C).

4. The Rechargeable LED Lightsource can be controlled by the provided remote control.

Before using the Rechargeable LED Lightsource check that the battery is fully charged. If the light is dim, fully charge the Rechargeable LED Lightsource. While charging, the indicator will turn red and will turn green when fully charged.