

UTTERMOST

ASSEMBLY INSTRUCTIONS

CAREFUL UNPACK ALL LAMP PARTS FORM THE CARTON

1. Please place Harp onto Saddle, and place Uttermost Disk onto Harp.
2. Please place Shade onto Uttermost Disk, then fasten Finial onto Harp to fix Shade.
3. Install correct Bulb (Included) referring to fixture markings.

