

REVELATION

by UTTERMOST




MANUFACTURERS OF WALL DECOR, LIGHTING, RUGS, DECORATIVE ACCESSORIES AND ACCENT FURNITURE


Assembly Instruction STYLE:R19993

Parts list


A	TOP PART	1PCS
B	MIDDLE PART	1PCS
C	BOTTOM PART	1PCS

Hardware list


	WRENCH	1PCS
	FLAT WASHERS	2PCS
	BOLT	2PCS



1. Take the parts carefully out of the carton. and then place them on a flat and soft surface, making sure that the parts will not be damaged.



2. Place the bottom part on a flat and soft surface, then bolt the middle part into the bolt holes under the bottom part and then use wrench to secure tightly.



3. Put the top part on the middle part and the assembly is completed.

To clean, wipe with soft dry cloth.