

REVELATION

by UTTERMOST

ASSEMBLY AND INSTALLATION INSTRUCTIONS

R21310

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

Installation Steps

1. Carefully unpack your new fixture and lay out all the parts on a clear surface.
 2. Thread the Rod into the coupling.
 3. Thread Hex nut-2 onto Nipple, insert Lock washer over the end of Nipple, thread Nipple through Mounting bar and secure with Hex nut-1 continue until tight.
 4. Thread Green ground screw into the hole near the two dimples of Mounting bar. Secure Mounting bar to outlet box with Outlet box screws.
 5. Thread the Collar loop onto the Nipple-1. Slide the Collar ring and the Canopy over the Chain. Open one link of Chain, connect it to fixture Loop. Open the other one link of Chain, connect it to Collar loop and close the link.
 6. Lace wires up through Chain and pas wires through holes in Collar loop. We recommend lacing wire up through every other link of Chain.
 7. Make Wire connections with Wire Connector:
 - The smooth wire (w/ marking) from fixture to Black Wire from power source.
 - The ribbed wire (w/o marking) from Fixture to White Wire from power source.
 - Attach the Ground Wire and house ground wire to the Mounting bar with the green Ground screw.Carefully tuck wires back into the Outlet box.
 8. After wires are connected, place the Canopy on the ceiling and secure Collar ring. Then tuck them carefully inside outlet box.
 9. Install the light bulbs in accordance with the fixture's specifications.
- DO NOT EXCEED THE MAXIMUM WATTAGE RATING!**
10. Thread the Nipple-2 onto the Tube.
 11. Turn on the power at fuse or Circuit Box.

