

REVELATION

by UTTERMOST

ASSEMBLY AND INSTALLATION INSTRUCTIONS

R21338

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF POWER BEFORE INSTALLING OR SERVICING THIS FIXTURE.

Installation Steps

1. Turn on the power at fuse or Circuit Box. Turn power off before starting.
2. Carefully unpack your new fixture and lay out all the parts on a clear surface.
3. Thread the Coupling-2 onto the Nipple.
4. Thread the Center stem into the Coupling-1 and onto the Swivel.
5. Thread the Mounting screws into the matching holes of the Circular strap, and tighten with the Hex nut. Thread the Ground screw into the hole of the Circular strap. Secure the Circular strap to the outlet box with the Outlet box screws.
6. Attach the Hook on the end of the Support cable to the Circular strap.
7. Make Wire connections with Wire Connector:
 - The smooth wire (w/ marking) from fixture to Black Wire from power source.
 - The ribbed wire (w/o marking) from Fixture to White Wire from power source.
 - Attach the Ground Wire and house ground wire to the Circular strap with the green Ground screw.Carefully tuck wires back into the Outlet Box.
8. Place the fixture Canopy over the two Mounting screws so they protrude through the holes in the Canopy. Thread the Ball nut onto the Mounting screws and continue turning until the fixture is snug against the ceiling.
9. Connect the top of Chain to the Hook, then use Quick link to connect Metal frame and the bottom of Chain
10. Place the Cap onto the Socket cup.
11. Install the light bulbs (Not Supplied) in accordance with the fixture's specifications.

DO NOT EXCEED THE MAXIMUM WATTAGE RATING!

