


Illustration

ITEM NO.:R22565



P.O. Box 558 | 3325 Grassy Hill Road | Rocky Mount, VA | 24151 www.uttermost.com/Revelation



Parts and Hardware List

ITEM NO: R22565

Α.	Hex screw	4PCS
В.	Universal Bar	1PC
C.	Mounting Screw	2PCS
D.	Green Ground Screw	1PC
Ε.	Wire Nut	3PCS

WARNING: <u>BEFORE INSTALLING</u>, make sure the electricity supply is shut off to avoid a possible electric shock. We suggest a licensed electrician for all installations.

- 1. Carefully remove the parts and hardware from the carton.
- 2. Fasten the Universal bar onto the Outlet Box using the mounting screw.
- 3. Install both ground wires in the Universal bar with the Green Ground Screw supplied.
- 4. Place the white wire, ribbed or tinted wire evenly against the white wire from the outlet box and place the black, smooth or un-tinted wire evenly against the black wire from the outlet box. (Connecting the Wires See Figure 2)
- 6.Attach the backplate to fix universal bar, and secure with the hex screw.
- 7.Install 2*60 Watt max, Type B bulb (NOT INCLUDED) into the socket of the fixture.
- 8. Carefully screw the alabaster discs onto the rod ends until tight, following disc sizes guide in drawing.

P.O. Box 558 | 3325 Grassy Hill Road | Rocky Mount, VA | 24151 www.uttermost.com/Revelation