


REVELATION

by UTTERMOST

MIRRORS • ALTERNATIVE • WALL DECOR • ART • ACCESSORIES • CLOCKS • RUGS • LIGHTING • ACCENT FURNITURE

Assembly Instruction STYLE:R24918



Parts list

A	Table Top	1 PC
B	Table Leg	4 PCS

Hardware list

a	Allen Key	1 PC
b	Bolt	16 PCS
c	Flat Washer	16 PCS
d	Plastic Washer	32 PCS
e	Nut	16 PCS

1. Take the Parts carefully out of the carton, and then place them on a flat and soft surface, making sure that the parts will not be damaged.

2. Place Table Top (A) upside down on a flat soft surface. Install Table Legs x4(B) individually as shown.

3. Assembly complete. Turn table over and adjust level by turning foot levelers on bottom if needed.

To Clean, wipe with soft dry cloth.

PO BOX558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151

www.uttermost.com