

# REVELATION


by UTTERMOST

## ASSEMBLY INSTRUCTIONS

**STYLE# R28150**

*Careful unpack all lamp parts from the carton.*

1. Place the Base in an upright position on the floor
2. Thread **Part A** onto the lamp **Base** and turn clockwise to tighten secured.
3. Carefully lay the assembled pieces on a soft surface and attach the **Rubber Washer**, **Flat Washer** and **Hex Nut** to the threaded pipe under the **Base**. Use **Wrench** to tighten. This tightens the entire lamp **Base**.
4. Place the **Glass** onto the **Part A** with protection **Clear PVC Washer** in between as shown on the drawing.
5. Push the **Excessed wire** back into the **2"D Tube** trough **5/8" Nipple**
6. Thread **Clear PVC Washer** and **Part B** into the threaded pipe under the Glass by turning **Part B** clockwise to tighten until snug.
7. Thread **Part C** into **Part B** by turning **Part C** clockwise to tighten until snug.
8. Thread **Harp** into **Part C** by turning **Harp** clockwise to tighten until snug.
9. Place the **Shade** over the top end of the **Harp**. Secure by thread the **Finial** onto the **Harp**. Hand tighten until snug.
10. Install correct Bulbs referring to fixture markings and /or labels for maximum wattage. (Not Included)



R28150

## IMPORTANT SAFETY INSTRUCTIONS

This portable lamp has a polarized plug ( one blade is wider than the other ) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151

[www.revelationbyuttermost.com](http://www.revelationbyuttermost.com)