

# REVELATION


by UTTERMOST

## ASSEMBLY INSTRUCTIONS

STYLE#: R28172-1

**Careful unpack all lamp parts from the carton.**

1. Take the lamp carefully out of the Carton, and place it on a flat surface.
2. Thread **Part A** into the **Base** by turning **Part A** clockwise to tighten until snug.
3. Thread **Part B** into **Part A** by turning **Part B** clockwise to tighten until snug.
4. Thread **Part C** into **Part B** by turning **Part C** clockwise to tighten until snug.
5. Thread **Part D** into **Part C** by turning **Part D** clockwise to tighten until snug.
6. Locate the **Harp** by pressing the ends of the **Harp** into the **Harp Base** on the top of **Base**.
7. Place the **Shade** over the top end of the **Harp**. Secure by thread the **Finial** onto the **Harp**. Hand tighten until snug.
8. Install correct Bulbs referring to fixture markings and /or labels for maximum wattage. (Not Included)



## IMPORTANT SAFETY INSTRUCTIONS

This Floor lamp has a polarized plug ( one blade is wider than the other ) as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not attempt to defeat this safety feature.

PO BOX 558/3325 GRASSY HILL RD. ROCKY MOUNT, VIRGINIA 24151

[www.revelationbyuttermost.com](http://www.revelationbyuttermost.com)