



UTTERMOST

THANK YOU FOR PURCHASING
THE FLOOR LAMP .
PLEASE FOLLOW THE INSTRUCTIONS
LISTED BELOW:

**ASSEMBLY INSTRUCTIONS:
MODEL NUMBER:30071-1**

- 1.UNPACK ALL PARTS FROM CARTON
CAREFULLY;
- 2.INSTALL 40 WATT, EDISON BULB (NOT INCLUDED)
INTO THE SOCKET OF THE LAMP.
3. PLACE GLASS SHADE "A" INSIDE
OF THE METAL CUP "B" PROPERLY.
4. IF THE LAMP GET LOOSE DURING
SHIPPING, PLEASE SCREW THE TIGHTEN
METAL NUT "C" BY HAND.

40 WATT,EDISON BULB
,NOT INCLUDED)

