



Assembly Instruction



STYLE NO.: W26036-1

1. Take the parts carefully out of carton, and place them on a flat surface, make sure that the parts will not be damaged.
2. Screwing Tude B to Lamp Body A until tightly,
3. Screwing Tude C to Tude B until tightly,
4. Screwing Tude D to Tude C until tightly,
5. Screwing Lamp body E to Tude C until tightly,
6. Screwing Lamp body F to Lamp Body E until tightly,
7. Attach the harp onto the saddle as drawing.
8. Place the shade onto the top of the harp, then tighten the finial clockwise until secure.

CAUTION: IN ACCORDANCE WITH THE UL REGULATION, THE SHADE SHOULD BE OPEN TOP & OPEN BOTTOM AND "CD" IS BIGGER THAN OR EQUALS TO 4-1/2", "R" IS NOT SMALLER THAN 4-3/4" OR MAY CAUSE FIRE. "H" IS 3 1/4".

To clean, wipe with soft dry cloth.

NOTE: THE DRAWING OF THE LAMP BODY IS FOR REFERENCE ONLY.