





Assembly Instruction



STYLE NO.: W26043-1

1. Carefully unpack carton and place all parts on a soft, smooth surface. Inventory all parts.
2. Screw and tighten lamp body A onto lamp body B.
3. Place Harp into Saddle of socket .
4. Place the shade onto the top of the harp, then tighten the finial clockwise until secure.



CAUTION; IN ACCORDANCE WITH THE UL REGULATION, THE SHADE SHOULD BE OPEN TOP&OPEN BOTTOM AND "CD" IS BIGGER THAN OR EQUALS TO 4, "R" IS NOT SMALLER THAN 3-1/2" OR MAY CAUSE FIRE "H" IS 3-1/4"

To clean, wipe with soft dry cloth.

NOTE: THE DRAWING OF THE LAMP BODY IS FOR REFERENCE ONLY.