



Assembly Instruction



STYLE NO.: W26054-1

1. Carefully unpack carton and place all parts on a soft, smooth surface. Inventory all parts.
2. Screw and tighten lamp body A onto lamp body B.
3. Place Harp into Saddle of socket .
4. Place the shade onto the top of the harp, then tighten the finial clockwise until secure.



CAUTION: IN ACCORDANCE WITH THE UL REGULATION, THE SHADE SHOULD BE OPEN TOP & OPEN BOTTOM AND "CD" IS BIGGER THAN OR EQUALS TO 4-1/2", "R" IS NOT SMALLER THAN 4-3/4" OR MAY CAUSE FIRE. "H" IS 3 1/4".

To clean, wipe with soft dry cloth.

NOTE: THE DRAWING OF THE LAMP BODY IS FOR REFERENCE ONLY.