ASSEMBLY INSTRUCTIONS MODEL NUMBER W26102-1 THANK YOU FOR PURCHASING THIS TABLE LAMP. PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

CAUTION: DO NOT PLUG INTO WALL OUTLET BEFORE ASSEMBLY. UNPLUG WHEN REPLACING THE LAMP BULB.

- 1. Carefully unpack carton and place all parts on a soft, smooth surface. Inventory all parts.
- 2. Thread the socket (B) clockwise to body (A)
- 3. Attach harp (D) into the saddle (C).
- 4. Place the shade (E) onto top of harp (D).
- 5. Screw and tighten Finial (F), clockwise onto harp (D).

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other), as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter this plug.

Care and Maintenance

To clean, wipe with a soft dry cloth.

ASSEMBLY INSTRUCTIONS MODEL NUMBER W26102-1 THANK YOU FOR PURCHASING THIS TABLE LAMP. PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

CAUTION: DO NOT PLUG INTO WALL OUTLET BEFORE ASSEMBLY. UNPLUG WHEN REPLACING THE LAMP BULB.

- 1. Carefully unpack carton and place all parts on a soft, smooth surface. Inventory all parts.
- 2. Thread the socket (B) clockwise to body (A)
- 3. Attach harp (D) into the saddle (C).
- 4. Place the shade (E) onto top of harp (D).
- 5. Screw and tighten Finial (F), clockwise onto harp (D).

IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other), as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter this plug.

Care and Maintenance

To clean, wipe with a soft dry cloth.



