

ASSEMBLY INSTRUCTIONS


MODEL NUMBER W26104-1

THANK YOU FOR PURCHASING THIS TABLE LAMP.

PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

**CAUTION: DO NOT PLUG INTO WALL OUTLET BEFORE ASSEMBLY.
UNPLUG WHEN REPLACING THE LAMP BULB.**

1. Carefully unpack carton and place all parts on a soft, smooth surface. Inventory all parts.
2. Screw Tube (B) to base (A) until tight. Carefully pull excess cord through lamp base during assembly.
3. Screw Tube (C) to Tube (B) until tight
4. Screw Tube (D) to Tube (C) until tight.
5. Screw Part (E) to Tube (D) until tight.
6. Screw Tube (F) to Part (E) until tight.
7. Thread Part (I) into Part (E), with screws (G) by using the Allen wrench (H) provided. Turn screws (G) clockwise to tighten.
8. Remove socket ring (L) from lamp holder (J).
9. Place shade (K) onto lamp holder (J)
10. Screw and tighten socket ring (L) onto lamp holder (J) to secure shade.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other), as a safety feature to reduce the risk of electric shock.

This plug will fit in a polarized outlet only one way.

If it does not fit fully in the outlet, reverse the plug.

If it still does not fit, contact a qualified electrician.

Never use with an extension cord unless plug can be fully inserted.

Do not alter this plug.

Care and Maintenance

To clean, wipe with a soft dry cloth.