


ASSEMBLY INSTRUCTIONS
MODEL NUMBER W26124-1
THANK YOU FOR PURCHASING THIS TABLE LAMP.
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

CAUTION: DO NOT PLUG INTO WALL OUTLET BEFORE ASSEMBLY.
UNPLUG WHEN REPLACING THE LAMP BULB.

1. Carefully unpack carton and place all parts on a soft, smooth surface. Inventory all parts.
2. Thread the tube (D) clockwise to part (G).
3. Thread the tube (C) clockwise to tube (D).
4. Thread the tube (B) clockwise to tube (C).
5. Thread the tube (B) clockwise to base (A).
6. Thread the tube (H) clockwise to part (G).
7. To adjust the height of the lamp: Loosen the Adjusting Screw (E) to place the Adjustable Tube (F) in the desired position, then tighten the Adjusting Screw (E) to secure the position.



IMPORTANT SAFETY INSTRUCTIONS:

This portable lamp has a polarized plug (one blade is wider than the other), as a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If it does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter this plug.

Care and Maintenance

To clean, wipe with a soft dry cloth.