


REVELATION

by UTTERMOST

Thank you for purchasing a Revelation lamp. We hope you are as proud to display this lamp as we were to make it.

Assembly Instructions

1. Remove the wrapping on the lamp shade, be careful not to damage the shade.
2. The finial disk is to be placed on the top of shade spider, under the finial, as shown in the diagram.
3. Place harp onto saddle, then place the shade onto the harp.
4. Place finial disk then fasten finial onto harp to fix shade.



IMPORTANT SAFETY INSTRUCTION:

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER). AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.