

Illustration

STYLE NO. : R21650




Figure 1







FIGURE 2-Wire Nut




Canopy glass 2PCS



L6" Metal Tube #4



L12" Metal Tube #2



L12" Metal Tube #1





FIGURE 3

Add swivel as needed

ITEM NO. :R21650

Parts and Hardware List

A.	Wire Nut	3PCS
B.	Green Ground Screw	1PC
C.	Crossbar	1PC
D.	Hex Nut	2PCS
E.	Pre-Threaded Pipe	1PC
F.	Outlet Box Screw	2PCS
G.	Canopy	1PC
H.	Pre-threaded Ring	1PC
I.	Swivel	1PC

J.	Safte cable	1PC
K.	Coupling	1PC
L.	L6" metal tube	1PC
M.	L12" metal tube	3PCS

Please read Wiring Instructions before you begin assembling and installing your Ceiling Fixture. Please make sure that you have all the parts indicated before you begin assembling this item.

WARNING: BEFORE INSTALLING, make sure the electricity supply is shut off to avoid a possible electric shock.We suggest a licensed electrician for all lighting fixture installations.

HEAVY WEIGHT FIXTURE OVER 50 LBS., MUST FOLLOW NEC ARTICLE 314.27 (2) for heavy weight installation; Fixtures that weigh more than 50 lbs. shall be supported independently of the outlet box, unless the outlet box is listed for not less than the weight to be supported, and the box shall be marked by box manufacturer to indicate the maximum weight it shall support.

1. Take the parts carefully out of the carton, place them on a flat surface, and make sure that the parts will not be damaged.
- 2.The weight of this fixture will require a means of support inependent of the outlet box .This fixture must be supported by Pre-Threaded Pipe.The Pre-Threaded Pipe should be positioned so that 3/4" protrudes into the outlet box cavity.
- 3.With the Pre-Threaded Pipe properly situated, locate the Coupling (K) and proceed to thread onto the end of the Pre-Threaded Pipe protruding into the outlet box. Thread the Couping(K) onto the pipe until tight.
- 4.Insert the shorter end of the Pre-Threaded Pipe (E) into the pre-drilled hole in the Crossbar (C) and secure with the Hex Nuts (D). (See illustration)
5. Attach the Pre-threaded metal part to the exposed end of the Pre-Threaded Pipe (E) and secure by turning in a clockwise direction.
6. Adjust the length of the wire needed for your installation, remove excess, determine the number of Rods to be assembled to the Fixture Body as needed for your hanging height,then the metal tube #1 passes through the wire and screw the Lamp body onto the Metal Tube #1 until tight.
7. Repeat Step 6 with the Metal Tube #2,#3 and #4 as needed for your installation height.
8. You can add swirl as needed(See Figure 3). If you don't need swivel, you can screw the metal tube #4 on canopy directly.
9. Install both ground wires in the Crossbar (C) with the Green Ground Screw (B) supplied.
10. Place the white wire, ribbed or tinted wire evenly against the white wire from the outlet box and place the black, smooth or un-tinted wire evenly against the black wire from the outlet box. (Connecting the Wires - See Figure 2)
11. After the wires are connected, tuck them carefully inside the outlet box.Place the two pieces of canopy glass through the pre-threaded metal part,and then place the Canopy (G) over the outlet box and secure with Pre-Threaded Ring (H).
12. Install 10*60W max, Type B bulbs (NOT INCLUDED) into the socket of the fixture.
13. Hang the glass panels in the hook of lamp body through glass holes as following guide in drawing.