





THANK YOU FOR PURCHASING THE TABLE LAMP .
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

ASSEMBLY INSTRUCTIONS:
MODEL NUMBER:W26026-1

1. UNPACK ALL PARTS FROM CARTON CAREFULLY;
2. THREAD THE SOCKET ASSEMBLY("B") CLOCKWISE TO THE BODY ("A")
3. ATTACHED THE HARP("D") INTO THE SADDLE("C")
4. PLACE THE SHADE("E") ONTO THE TOP OF HARP("D") , AND SCREW THE FINIAL ("F") CLOCKWISE TO FIX THE SHADE

IMPORTANT SAFETY INSTRUCTION:

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER). AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.



THANK YOU FOR PURCHASING THE TABLE LAMP .
PLEASE FOLLOW THE INSTRUCTIONS LISTED BELOW:

ASSEMBLY INSTRUCTIONS:
MODEL NUMBER:W26026-1

1. UNPACK ALL PARTS FROM CARTON CAREFULLY;
2. THREAD THE SOCKET ASSEMBLY("B") CLOCKWISE TO THE BODY ("A")
3. ATTACHED THE HARP("D") INTO THE SADDLE("C")
4. PLACE THE SHADE("E") ONTO THE TOP OF HARP("D") , AND SCREW THE FINIAL ("F") CLOCKWISE TO FIX THE SHADE

IMPORTANT SAFETY INSTRUCTION:

THIS PORTABLE LAMP HAS A POLARIZED PLUG(ONE BLADE IS WIDER THAN THE OTHER). AS A SAFETY FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT A QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

